

# FamilyRolls



## DC166A & DC862A

### Controller Specification

Version NO.: A/00



#### Receiver specification


Technical support



- ① Group control channel match code, delete code, convert direction all unworkable
- ② The DC166A controller includes a DC154 receiver and two DC279 emitters.

- Dial reversing function.
- Dial switch over mode.
- Connecting with Electronic switch is available (company matched).
- Connecting with a bulb is available (company matched).
- Emitter with key for light bulb can make the light bulb lighten or go out circulately.
- Need not press any button of emitter within three minutes, the light bulbs go out.
- Standard type DC154 can store 30 effective channels, over 20 channels, if still add new channel, only last channel will be repeating

#### Control range



Effective transmitting distance may have deviation due to actual environment

	L1 open	L1 partition	Emission frequency
120V/60Hz	200m	35m	433.92MHz
230V/50Hz	200m	35m	433.92MHz




#### Matchable emitter

Technical support




You can press up button and stop button at the same time to work as the same function as setting button




#### Matchable Motor and button specification

Technical support




#### Mode of connection

Technical support



#### The best installation distance



- ① The shortest distance between receiver and ground ≥ 0.3m
- ② The shortest distance between receiver and roof ≥ 0.2m
- ③ The shortest distance between receiver and receiver ≥ 0.3m


# A

## Setting up and adding up

Additional function

The interval of different button must within 10 seconds for all setting, otherwise the system will restore the original state

One receiver store 20 emitters channels at most, and one channel of emitter can control 20 receivers at most.




# A

## Delete one emitter channel

Additional function

One channel is cancelled successfully




# A

## Delete all the emitter channels

Additional function


Delete all the emitter channels successfully



# A

## Dial toggle switch to change directions

Additional function



# A

## Common mode

Additional function



# A

## Safety mode

Additional function

1 Don't release the down button tubular motor rotate down continuously

